

# Classroom AV Control System Operation Guide

For technical support, please call : 8822 2511  
Hours of service: Monday to Friday (except holiday)  
08:00-19:30

# 1

## SYSTEM ON



SYSTEM ON

To activate the system, press this button and wait until it directs you to the main page

## SYSTEM OFF



Press the POWER button on the lower right corner and then select  to shut down the system

Please browse through our Facility Management and Maintenance Section (FMM) website for more operation guidelines

Report any problems by raising work orders through Computerised Maintenance Management System (CMMS)



# 2

## SOURCE SELECTION PAGE



Next page for more options



## Projector Input Source Selection

Select icon of desired input source to transmit video signal to projector:


- Notebook VGA
- Visualizer
- Table AUX
- Notebook HDMI
- Blu-ray player
- Desktop

## Select VGA or HDMI connection from notebook to projector

- ① Please use attached VGA or HDMI cable to connect your notebook



- ② Choose desired input source (VGA or HDMI) on the Source Selection Page



- ③ Press Fn and F(X) on keyboard simultaneously to change display sources. F(X) could be either one of the keys from F1 to F12, which has a printed logo of "CRT/LCD"



# 3

## MULTIMEDIA CONTROL PAGE



- MEDIA VOLUME → Multimedia Volume Control Page
- MIC. VOLUME → Microphone Volume Control Page
- BLU-RAY PLAYER → Blu-ray Player Control Page
- PROJECTOR → Projector Control Page for display alignments

# 4

## SCREEN CONTROL

- ① Press to enter Screen Control Page
- ② Raise or lower the screen on the Screen Control Page